




XAS702-01

INSTRUCTION MANUAL

If you have any questions along the way, just give us a call
1-800-460-0956 or message to us. We're ready to help!

⚠ CAUTION: PLEASE READ ENTIRE MANUAL PRIOR TO USE AND SAVE THESE INSTRUCTIONS.

Before getting started, let's check below lists to make sure it is just right for you!

<p>1</p> <p>Is the width of your wall plate 16" or less than 16"?</p>	<div data-bbox="483 341 808 587">  </div> <div data-bbox="860 421 1368 528"> <p>Yes --- Perfect!</p> <p>No --- This mount is NOT compatible.</p> </div>
<p>2</p> <p>Does your TV (including accessories) weigh less than 154 LBS (70 kg)?</p>	<div data-bbox="470 651 707 815">  </div> <div data-bbox="786 708 1301 815"> <p>Yes --- Perfect!</p> <p>No --- This mount is NOT compatible.</p> </div> <div data-bbox="1339 635 2132 858"> <p>⚠ CAUTION: DO NOT exceed the maximum weight indicated. This mounting system is intended for use only with the maximum weights indicated. Use with products heavier than the maximum weights indicated may result in collapse of the mount and its accessories, causing possible injury.</p> </div>
<p>3</p> <p>What is your wall made of?</p>	<div data-bbox="470 879 853 1066">  <p>Drywall with wood studs?</p> </div> <div data-bbox="887 879 1093 1054"> <p>⚠ CAUTION: DO NOT install into drywall alone</p> </div> <div data-bbox="1200 879 1700 1054"> <p>? Unsure?</p> <p>Call Customer Service: 1-800-460-0956</p> </div>
<p>4</p> <p>Do you have all the tools needed? (NOT INCLUDE)</p>	<div data-bbox="528 1107 624 1235"> <p>Tape Measure</p> </div> <div data-bbox="651 1107 745 1235"> <p>Pencil</p> </div> <div data-bbox="763 1107 871 1235"> <p>Level</p> </div> <div data-bbox="891 1107 981 1235"> <p>Screw driver</p> </div> <div data-bbox="999 1107 1111 1235"> <p>Electric Drill</p> </div> <div data-bbox="1126 1107 1245 1235"> <p>1/2 in. (13 mm) Socket Wrench</p> </div> <div data-bbox="1279 1082 1346 1321"> <p>Wood Stud Install</p> </div> <div data-bbox="1406 1091 1487 1235"> <p>Stud Finder</p> </div> <div data-bbox="1543 1091 1671 1235"> <p>7/32 in. (5.5 mm) Wood Drill Bit</p> </div> <div data-bbox="1749 1107 1861 1235"> <p>Hammer</p> </div>
<p>CAUTION</p> <p>5</p>	<ul style="list-style-type: none"> • This product is designed for use in wood stud, solid concrete walls - DO NOT install into drywall alone • The wall must be capable of supporting five times the weight of the TV and mount itself • Do not use this product for any purpose not explicitly specified by manufacturer • Manufacturer is not responsible for damage or injury caused by incorrect assembly or use

Parts and Hardware


⚠ WARNING: This product contains small items that could be a choking hazard if swallowed. Before starting assembly, verify all parts are included and undamaged. If any parts are missing or damaged, do not return the damaged item to your dealer; contact Customer Service.

Never use damaged parts!

📋 NOTE: Not all hardware included will be used.


Parts and Hardware for STEP 1

Lag Bolt




01 x4

M8 Washer




02 x4

Bolt M8x20mm



03 x4

M8 Washer




04 x4

Allen Key




05 x1

Wall plate bar



06 x2







Sliding block




07 x4

STEP 1 Attach Brackets to TV

1-1 Select TV Screws



1-2 Wall plate bar与电视架组装





STEP 2 Attach Wall Plate to Wall

⚠ CAUTION: Avoid potential personal injury or property damage!

- Drywall covering the wall, must not exceed 5/8 in. (16 mm)
- Minimum **wood stud** size: common 2 x 4 in. (51 x 102 mm) nominal 1½ x 3½ in. (38 x 89 mm)
- Maximum horizontal space between fasteners: 16/24 in. (406/609 mm)
- Stud center must be verified

1. Locate your studs. Verify and mark the center of the stud by finding the stud edges using a thin nail, or an edge to edge stud finder.
2. Position the mounting template at your desired height and line up the holes with your stud center line. Level the wall plate and mark the hole locations.





3. Drill pilot holes using a 7/32 in. (5.5 mm) diameter drill bit.

! IMPORTANT: Pilot holes must be drilled to a depth of 2.5 in. (64 mm). Be sure to drill into the center of the studs.

4. Install wall plate **08** using four lag bolts **01** and four washers **02**. Tighten the lag bolts only until they are pulled firmly against the wall plate.




! CAUTION: Improper use could reduce the holding power of the lag bolt.
DO NOT over-tighten the lag bolts.

Go to STEP 3 on PAGE 8.



STEP 3 Wall Plate Installation Integrity Test

Before hanging TV, please try to pull the mount to make sure that it has been assembled on the wall tightly.



STEP 4 Adjustment

Locate the wall mount unit by sliding left or right then tighten Bolts **03** with Allen Key **05** to lock the mount at desired position.

